




activTek INDUCT 500



SINGLE ROOM AIR SYSTEM

**description**

- Compact, self contained, natural air treatment system
- Discreet internal mounting
- No cleaning required

**applications**

- Room size “In-Wall,” P-TAC, or “Stand-Alone” Heating/AC units
- Hotel rooms
- Motel rooms
- Offices

**the technology**

The activTek INDUCT 500 utilizes tested ActivePure® technology to substantially reduce odors, visible smoke in the air, and treat contamination on surfaces. Designed to be installed inside the ductwork of an in-wall heating and air

conditioning unit, INDUCT 500 is compact, self-contained, and requires no cleaning. Covers up to 500 square feet. Professional installation recommended.

Published scientific studies conducted on behalf of activTek by Dr. James Marsden at Kansas State University demonstrated that activTek's ActivePure® technology substantially reduces microbial populations on surfaces. The study's results have not been reviewed by the FDA, EPA or any other governmental agency. Our products are not medical devices and are not intended to diagnose, treat, or cure any disease.



**specifications**

INDUCT 500	US40509	
electrical	15VDC Input, .1 Amps, 100 – 240 VAC, 50/60 HZ	5 Watts* – Switching Power Supply
mechanical	retainer clip included	
dimensions	10.38" L x 2.25" W x 1.25" H	28.37cm L x 5.72cm W x 3.175cm H
weight	2.9 pound	1.3 kilograms
hvac air blower	250 SCFM recommended air flow	

The activTek INDUCT 500 is ideally applicable to be installed inside of the ductwork of “Stand-Alone” or typical “In-Wall” air handler units.

## applications list

---


- Hotel rooms
- Motel rooms
- Cabins
- Efficiency apartments
- Nursing home rooms
- Offices

## installation details

---

The activTek INDUCT 500 is intended to be installed inside of a typical in-wall unit.

- They are to be installed in the duct after the fan.
- Recommend 250 CFM air flow for optimal use.
- Please contact your Distributor with the make and model for compatibility and specific installation instructions.
- Installation must be by licensed HVAC professional.



## danger!

---

**DANGER:** Never look directly at the unit while it is in operation. The activTek INDUCT 500 utilizes high-intensity Ultraviolet light which can cause damage to your eyes. Always install the activTek INDUCT 500 at least 24” back

from the opening. Shield the unit as necessary to prevent direct line-of-sight vision of the unit. Always use approved safety equipment when working near UV light.

Distributed By: